



HIGH PERFORMANCE DRY VACUUM PUMP

No. 21.819W - 110 olt
No. 21.819WX - 220 volt

OPERATING INSTRUCTIONS



WARNING

**Not recommended for pumping acid, base or organic vapors or gases.
Be sure to properly identify intake and discharge before using pump.**

INSTALLATION

This manual has been compiled not only for the care and maintenance of the Grobet Dry Vacuum pump now in your possession, but as a helpful reference and guide to prevent many problems which can occur if used improperly.

UNPACKING

Carefully remove the Dry Vacuum pump from the shipping case and unfasten and remove wooden skid. Preserve all paperwork for future reference. If damage has occurred from shipment a claim must be filed with the carrier immediately. Preserve the shipping carton for inspection by the carrier. If you are required to communicate with your dealer or Grobet Vacuum be sure to include your order numbers for quick identification. Do not return the pump to the factory without first calling for a returned goods number.

PUMP MOUNTING

Rubber feet are attached to the pump. Rubber feet are excellent for applications involving a semi-flexible surface such as a bench top; they help to isolate noise and eliminate creeping. All models of Dry Vacuum Pumps should be mounted in a horizontal plane.

PUMP LOCATION

The pressure/vacuum pump should be located preferably in a clean, dry and well-ventilated area. Please be sure not to block the ventilation ports located on the motor housing. The pump should be placed where the surrounding temperature remains between 10°C and 40°C (50°F and 104°F). Always check to insure the location choice is protected from direct or indirect moisture contact. Grobet recommends that the pump be installed at the highest point within the system to prevent possible water condensate from entering the pump. The pump should be located as closely to its system in order to utilize it most efficiently.

WARNING

**Don't pump flammable or explosive gases or vapors or operate this pump in an atmosphere containing flammable or explosive gases or vapors.
Bursting Hazard- use on exhaust port the silencer or air handling parts suitable for pressures not less than 100 PSIG**

INTAKE AND DISCHARGE PROVISIONS

The intake provision is a hose barb which accepts 3/8" ID vacuum hose . A silencer is supplied for the exhaust.

ELECTRICAL POWER SOURCE

Review the power source and the motor rating to be sure they agree in voltage, phase and frequency. Serious damage may occur to the motor if it is connected to an improper voltage. All Grobet pumps must be grounded. Grounding reduces the risk of electrical shock in the event of an electrical short circuit. The plug must be plugged into an outlet properly grounded. Consult your local electrical codes if you have doubts.


OVERLOAD PROTECTION

The motor manufacturer makes motor thermal overload protection available as an aid to minimizing motor failure. Overload protection is a standard feature on both 50 and 60 Hz single-phase motors. The motors have automatic overload protection. Automatic reset protection is designed to reset itself after a predetermined cooling period. If the fault to the drive remains unaltered, the motor will cycle on and off until fault is corrected.

WARNING

The motor is thermally protected and will automatically restart unexpectedly when the overload device resets.

IDENTIFICATION SYMBOLS



GROUNDING INSTRUCTIONS

This product should be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This product is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded in accordance with all local codes and ordinances.


DANGER

Improper installation of the grounding plug can result in a risk of electrical shock.

If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire.

Check with a qualified electrician or serviceman if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded. Do not modify the plug provided; if it will not fit the outlet, have the proper outlet installed by a qualified electrician.

This product is for use on a nominal 120V circuit, and has a grounding plug that looks like the plug illustrated in Sketch A in Figure #1. A temporary adapter, which looks like the adapter illustrated in sketches Band C, may be used to connect this plug to a 2-pole receptacle as shown in sketch B if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (Sketch A) can be installed by a qualified electrician. The green colored rigid ear, lug, etc. extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw.



The adapter shown in Figure B and Figure C is not acceptable in Canada.

EXTENSION CORDS

If necessary to use an extension cord, use a 3-wire extension cord that has a 3-blade grounding plug, and a 3-slot receptacle that will accept the plug on the product. Make certain your extension cord is in good condition. Make certain your extension cord wire size is not less than 18 guage for 25 feet, 16 guage for 50 feet, and 14 guage for 100 feet. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. If in doubt, use the next heavier cord. The smaller the guage number, the heavier the cord.

VACUUM CONNECTIONS

All Dry Vacuum Pumps come with intake and discharge hose barbs which accept 3/8" ID rubber pressure/vacuum hose. Hose clamps should be used to hold the hose in place. Since all four models operate in the viscous flow regime, the small diameter of the hose will generate minimal conductance loss. For best results, Grobet recommends the length of the tubing between the pump and the chamber be kept as small as possible.

VACUUM GAUGES

Typical in the rough vacuum range, a dial vacuum gauge is used to measure pressure in mm, Hg or inches of Hg. The dial vacuum gauge gives negative pressure – that is pressure below atmospheric. The reference point for the vacuum gauge is atmospheric pressure.

Please keep in mind that atmospheric pressure tends to vary from day to day. As a result of variability, the dial vacuum gauge will indicate slightly different maximum vacuum readings from day to day.

TRAPS

The pumps will handle humid air. All wetted aluminum parts are treated for corrosion protection from moisture. All other wetted parts are stainless steel. If there is a chance liquid may be drawn from the process under evacuation, Grobet recommends a liquid trap be placed between the process and the pump. A simple liquid trap is a filtering flask.

When a heavy load of water vapor is evolved from the vacuum process, a cold trap is recommended to help prevent damage to the pump mechanism.

The cold trap, immersed in a suitable Dewar flask, is installed so that the water vapor may come in contact with the surfaces of the trap and condense. Commonly used refrigerants are liquid nitrogen or dry ice and acetone or alcohol. Dry ice provides sufficient cooling to freeze out most heavy water vapor loads. A variety of cold traps are available from Grobet. The symptom of a high water vapor load is if you have droplets coming out of the exhaust port. If you see droplets of water, Grobet recommends you use a cold trap to capture the water before entering the pump or dilute the water vapor stream by adding dry nitrogen to the gas flow.

When using a cold trap the refrigerant should be maintained at a high level in the flask to keep the trap at a uniformly low temperature. If the trap is re-warmed it may allow re-evaporation of the condensate. The refrigerant add tube on the liquid nitrogen trap should not be obstructed as the refrigerant boil-off can produce dangerously high pressures. If the trap becomes saturated it should be disconnected from the system, drained and cleaned. An increase in pressure in the vacuum system will normally indicate that the trap has become saturated. To clean the trap, remove the trap from the system and allow the trap to warm up and rinse off the condensate with a suitable solvent in a fume hood. Thoroughly clean and dry the trap before reinstalling into the system.

OPERATION

STARTING A GROBET DRY VACUUM PUMP

Before attaching the pump to a system it is well to familiarize yourself with the function and action of the pressure vacuum pump that you have acquired. Review the power requirements as described in Electrical Power Section. Grobet recommends running the pump for a few minutes to warm up before use. The warm-up improves the pumps ability to handle humid air.

CLEANLINESS

Take every precaution to prevent foreign particulates from entering the pump. Particulates will damage the pump's performance. If you find that particulates will come off the process during evacuation, a particulate trap in the foreline will work. A simple, inexpensive trap may be made by placing glass wool in a glass or plastic tube. Screens must be inserted to hold the glass wool in place.

WARNING

The pump is not recommended for pumping acid, base or organic vapors or gases. Serious damage to the pump will shorten the pump's service life. In addition, pumping flammable vapors or gases can lead to serious safety hazard leading to fire or explosion.

LEAK DETECTION

The importance of eliminating all leaks in a vacuum system is obvious. The pump must remove this added volume of leaked gas to maintain the desired vacuum. Leaks for these pumps can be located by slightly pressuring the system and painting the suspected area with a thick soap solution. Escaping air will produce soap bubbles.

OPERATING PRESSURE RANGE

The Dry Vacuum Pumps are designed to be run from atmospheric to their maximum vacuum level on the intake side. Consult the Specification Table in the back of this manual for the ratings for your specific model.

SHUTDOWN PROCEDURES

After use, Grobet recommends the pump be run for about 2 minutes disconnected from the vacuum process. The air pumped through the mechanism will purge out water vapor or droplets of water condensate that may have formed on the inside of the pump. This purge of the pump mechanism helps prevent corrosion.

MAINTENANCE

Grobet dry pressure/vacuum units are 100% oil-free. The pump employs a non-lube piston and cylinder. No maintenance is necessary for the bearings. All bearings are sealed and permanently lubricated. Lubrication should not be attempted. The units are built for continuous duty operation with the quietness and durability of a diaphragm, but with piston performance.

TROUBLESHOOTING

VACUUM PROBLEMS

Leakage, contamination and unusual outgassing are the general causes of problems with poor vacuum. To operate at maximum efficiency a system must be thoroughly clean. If the system is completely clean and free from leaks, and unwarranted vacuum problems still exist, the pump should be checked. A simple criterion for the condition of the pump is the determination of its maximum vacuum capability. This can be accomplished by blocking of the intake and reading the vacuum level on the gauge.

TROUBLESHOOTING GUIDE

<u>Poor Pumping Speed</u>	<u>Poor Vacuum</u>	<u>Loud Unit</u>	<u>Possible Cause</u>	<u>Corrective Action</u>
X	X	X	Damaged Valves	Replace flapper valves
X	X	X	Debris in Valves	Remove debris and check for valve damage
X	X	X	Damaged Gaskets	Replace gaskets
X	X	X	Loose Head Screws	Tighten head Screws
X	X		Loose Fittings	Tighten fittings

WARRANTY

This Grobet product is warranted to be free from defects in material and workmanship. This liability of Grobet under this warranty is limited to servicing, adjusting, repairing, or replacing any unit or component part which in the judgment of Grobet has not been misused, abused, or altered in any way or damaged by ingestion of foreign material causing impaired performance or rendering it inoperative. No other warranties are expressed or implied. The method of executing this warranty: servicing, adjusting, repairing, or replacing, shall be at the discretion of Grobet Vacuum pumps that have been operated within a vacuum system, or other system, for any period, however short, will be repaired under this warranty rather than replaced.

The warranty is effective for one year from the date of original purchase when:

1. The warranty card has been completed and returned.
2. The product is returned to the factory or other designated service centers, freight prepaid.
3. The product in our judgment is defective through no action or fault of the user.

If the product has become defective through misuse, abuse, alteration, or ingestion of foreign material, repairs will be billed regardless of the age of the product. In this event, an estimate of the repair costs will be submitted and authorization of these charges will be required before the product is repaired and returned.

**ASK YOUR LOCAL DISTRIBUTOR FOR MORE
INFORMATION ON OTHER PRODUCTS BY GROBET USA™**



Carlstadt, NJ 07072