


INSTRUCTIONS FOR

TORCH-MATE


Automatic Torch Lighter
No. 14.204

Fig.1



Set switch to "I" position.
(Turn Torch Lighter "0" for
extended periods of disuse.)

Fig.2



To operate-Touch your torch
tip to the Activator Bar, a spark
at the flint will ignite the gas.